



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		85374A 3	DISTRIBUTOR ASSEMBLY, COM	1		
2		62426	SCREEN, VENT - DISTRIBUTOR	2		
3	43	73579	GEAR, DRIVE - MAIN SHAFT	1		
4	17	29077	ROLL PIN, DISTRIBUTOR GEAR	1		
5	26	72653	SEAL, HOUSING	1		
6		33653	FELT, BREAKER CAM LUBRICA	2		
7		72654	RETAINER, BREAKER CAM LUBF	1		
8		33665	PLATE, MOUNTING - BREAKER	1		
9	10	23977	SCREW, MOUNTING PLATE TC	2		
	12	62425	WASHER, BREAKER PLATE SUP	2		
10		33662	CONDENSER	1		
11		48024	BRACKET, CONDENSER MOUN	1		
12	10	48021	SCREW, CONDENSER BRACKE	1		
13		34235	BREAKER ASSEMBLY, DISTRIE	1		
14	10	33650	SCREW, BREAKER ASSEMBLY	1		
15	25	33666	GROMMET, MOUNTING PLATE	1		
16		33658	LEAD, PRIMARY	1		
17		58217	ROTOR, DISTRIBUTOR	1		
18		33667	CAP, DISTRIBUTOR	1		
19	10	33660	SCREW, DISTRIBUTOR CAP	1		
20	10	33663	SCREW, DISTRIBUTOR CAP	1		
21	24	73642	SPRING, DISTRIBUTOR SHAFT	1		
22	53	73499	LOCK RING, DISTRIBUTOR SH	1		
23		73501	DRIVE SHAFT, DISTRIBUTOR	1		
24	27	34486	GASKET, DISTRIBUTOR	1		4
25	84	92151A36	LEAD ASSEMBLY, HIGH TENSIO	4		
26	33	75340	SPARK PLUG (CHAMPION #RBL	4		
27		54676	RETAINER, HIGH TENSION LEA	1		
28	54	72821	CLAMP, HIGH TENSION LEADS	1		
29	16	73583	STUD, HIGH TENSION LEAD CL	1		
30	84	72825	WIRE, DISTRIBUTOR TO COIL	1		
31		32193A 2	COIL, IGNITION	1		
32		76354	BRACKET, IGNITION COIL MOUN	1		
33	10	66652	SCREW, MOUNTING BRACEKT	1		
34	12	30164	WASHER, IGNITION COIL TERMI	2		
34	13	26996	LOCKWASHER, IGNITION COIL T	2		
35	11	68219	NUT, IGNITION COIL TERMINAL	2		
36		67511	CLAMP UNIT, DISTRIBUTOR	1		
37	10	35386	SCREW, DISTRIBUTOR TO CYLI	1		
38	13	26993	LOCKWASHER, DISTRIBUTOR T	1		