



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		89953A	INTAKE MANIFOLD ASSEMBLY	1	
2	22	36382	PLUG, INTAKE MANIFOLD - TOI	1	
3	16	70236	STUD, CARBURETOR TO MANI	4	
4	10	28642	SCREW, DRIVE - WATER TUBE	2	
5	27	70905	GASKET, INTAKE MANIFOLD	1	4
6	10	68101	SCREW, INTAKE MANIFOLD TO I	7	
7	12	25909	WASHER, INTAKE MANIFOLD SC	7	
8		78801	LEVER, INTERMEDIATE THROTT	1	
9	12	35950	WASHER, INTERMEDIATE THRC	1	
10	12	30164	WASHER, INTERMEDIATE THOF	1	
11	11	20110	NUT, INTERMEDIATE THROTTLE	1	
12	10	38507	SCREW, LEVER TO INTAKE MAN	1	
13	12	20553	WASHER, LEVER TO INTAKE MA	1	
14	12	57792	WASHER, LEVER TO INTAKE MA	1	
15		27947	SWIVEL, LINKAGE	1	
16		64804	LINK ROD, LINKAGE	1	
17		63145A	LINK ROD ASSEMBLY, LINKAGE	1	
18		38983	SWIVEL, LINKAGE - CARBURETC	1	
19	12	35950	WASHER, SWIVEL LINKAGE - CA	1	
20	12	30164	WASHER, SWIVEL LINKAGE - CA	1	
21	11	20110	NUT, SWIVEL LINKAGE - CARBUI	1	
22	16	38525	STUD, THROTTLE CABLE ANCH	1	
23	12	24664	WASHER, THROTTLE CABLE AN	2	
24	11	20664	NUT, THROTTLE CABLE ANCHOI	1	
25	10	64969	SCREW, THROTTLE STOP	1	
26	11	33122	NUT, THROTTLE STOP SCREW	1	
27	32	90476	HOSE, MANIFOLD TO COOLER	1	
28	54	32780	CLAMP, HOSE TO COOLER	1	
29	54	32781	CLAMP, HOSE TO INTAKE MANIF	1	
30		89872	COOLER, ENGINE OIL	1	
31	22	48246	ELBOW, TO COOLER	2	
32	22	32802	PLUG, PIPE (1/8-27NPT)	1	
33	32	90477	HOSE, COOLER TO WATER PUM	1	
34	54	32780	CLAMP, HOSE ATTACHING	2	
35	32	89655	HOSE, INTAKE MANIFOLD TO EX	1	
36	54	32781	CLAMP, HOSE TO INTAKE MANIF	2	
37	22	75188	FITTING, BY-PASS - INTAKE MAN	1	