



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		864650A05	MODULE KIT, Fuel Pump, Complet	1		
1		892664	HOUSING, Fuel Module	1		
2		892677	COVER, Fuel Module Housing	1		
3	26	892683	SEAL	1		6
4	10	892684	SCREW	8		
5		892670A01	CHECK VALVE KIT	1		
6		NSS	NOT SOLD SEPARATE, Check	1		
7		NSS	NOT SOLD SEPARATE, Plug	1		
8		NSS	NOT SOLD SEPARATE, Seal	1		
9	16	865326	STUD, (M8 x 30)	1		
10		892681	REGULATOR	1		
11		866170A01	FUEL PUMP, Low Pressure	1		
12		NSS	NOT SOLD SEPARATE, Seal	1		6
13		NSS	NOT SOLD SEPARATE, Seal	1		6
14		NSS	NOT SOLD SEPARATE, Isolator,	1		6
15		866169A01	FUEL PUMP, High Pressure	1		
16		NSS	NOT SOLD SEPARATE, Isolator	1		6
17		NSS	NOT SOLD SEPARATE, Seal	1		6
18	84	895013A02	HARNES	1		
19		NSS	NOT SOLD SEPARATE, Retaine	1		
20		NSS	NOT SOLD SEPARATE, Screw	1		
21	35	892665	FILTER	1		
22		892687A02	FUEL CARTRIDGE	1		
23		NSS	NOT SOLD SEPARATE, Cap, f	1		
24		NSS	NOT SOLD SEPARATE, Scr	3		
25		NSS	NOT SOLD SEPARATE, Sea	1		6
26	35	866171A01	FILTER	1		
27		NSS	NOT SOLD SEPARATE, Sea	1		6
28		NSS	NOT SOLD SEPARATE, Cup, f	1		
29	10	866114	SCREW, (L250-28) Special	1		
30	22	88517	FITTING, Reducing	1		