



2184

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		863077T	ALTERNATOR ASSEMBLY, (Black)	1	(Non Serviceable)	
2	11	40021	NUT, (M6)	2		
3	10	40001134	SCREW, (M8 x 25)	1		
4	10	828213	SCREW, (.312-18 x 1.500)	2		
5	12	57792	WASHER	2		
6	11	859119	NUT, (.312-18)	2		
7		863211T01	BRACKET, Alternator Mounting	1		
8	10	98261	SCREW, (.375-16 x .750)	2		
9	12	20084	WASHER, (.328 x .562 x .062)	1		
10		862056T	BRACKET	1	SN# 0M614999 & Below	
10		864922T01	BRACKET	1	SN# 0M615000 THRU 0M639999	
10		865188001	BRACKET	1	SN# 0M640000 & Up	
11		862083T	BRACKET, Idler Adjusting	1		
12		818380T	BUSHING	1		
13	11	859135	NUT, (.437-20)	1		
14	43	818381	PINION STUD	2		
15		864625T	PULLEY, 4.25 Inch Diameter	1	(Power Steering)	
15		807757T	PULLEY, 3 Inch Diameter	1	(Compact Hydraulic Steering)	
16	10	34353	SCREW, (.375-16 x 1.00)	2		
17		862082T	BRACE, Power Steering Brace	1		
18	10	40001188	SCREW, (M10 x 20)	1		
19		862084T	BRACKET, Idler	1	(Bravo)	
20	11	32219	NUT, (.375-16)	2	(Bravo)	
21		862085T	BRACE, Idler Bracket	1	(Bravo)	
22		818382	PULLEY	1	(Bravo)	
23		818380T	BUSHING	1	(Bravo)	
24	10	56393	SCREW, (.437-20 x 1.75)	1	(Bravo)	
25	11	859135	NUT, (.437-20)	1	(Bravo)	
26	16	860102	STUD, (.375-16 x 1.730)	2	(Bravo)	
27		862778	BRACKET, Alternator Brace	1	(Alpha)	
28	10	34353	SCREW, (.375-16 x 1.00)	1	(Alpha)	
29	57	863876	BELT, Serpentine	1	(Alpha)(Power Steering)	
29	57	863876	BELT, Serpentine	1	(Alpha)(CHS and Non Power Steer	
29	57	863876	BELT, Serpentine	1	(Bravo)(Power Steering)	
29	57	863876	BELT, Serpentine	1	(Bravo)(CHS and Non Power Stee	1