



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	23	818465	BEARING SET	1	(STANDARD)	
1	23	818466	BEARING SET	AR	(.001 U.S.)	4
1	23	818467	BEARING SET	AR	(.010 U.S.)	4
1	23	818468	BEARING SET	AR	(.020 U.S.)	4
2		FI1100096	DOWEL PIN	2	(1/4 IN. DIA.)	
3	222	9520	FLYWHEEL	1		
4		18643A	COUPLING	1		
5	22	74036	FITTING	1	5.7L/LX ALPHA AND 5.7L BRAVO	
6		18644	RUBBER BUMPER	3	5.7L/LX ALPHA AND 5.7L BRAVO	
7	10	14883	SCREW	3	5.7L/LX ALPHA AND 5.7L BRAVO	
8	12	13510	WASHER	3	5.7L/LX ALPHA AND 5.7L BRAVO	
9		18311A17	COUPLING ASSEMBLY	1		
10	22	49099	GREASE FITTING	2	5.7LX BRAVO	
11	10	14883	SCREW	6		
12	12	20572	WASHER	6		
13	10	49845	SCREW	6		
14	429	9521	CRANKSHAFT	1		
15	28	34466	KEY	2		