



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	23	818465	BEARING SET	1	(STANDARD)	
1	23	818466	BEARING SET	AR	(.001 U.S.)	2
1	23	818467	BEARING SET	AR	(.010 U.S.)	2
1	23	818468	BEARING SET	AR	(.020 U.S.)	2
2		FI1100096	PIN-DOWEL (1/4 IN.)	2		
3	222	9520	FLYWHEEL	1		
4		18643A 5	COUPLING	1	5.7L/LX ALPHA/5.7L BRAVO/ AM	
5	22	74036	FITTING-GREASE	1	5.7L/LX ALPHA/5.7L BRAVO/ AM	
6		18644	RUBBER BUMPER	3	5.7L/LX ALPHA/5.7L BRAVO/ AM	
7	10	14883	SCREW (3/8-16 X 1-7/8 IN.)	3	5.7L/LX ALPHA/5.7L BRAVO/ AM	
8	12	13510	WASHER	3	5.7L/LX ALPHA/5.7L BRAVO/ AM	
9		18311A17	COUPLING ASSEMBLY	1	5.7LX BRAVO	
10	22	49099	FITTING-GREASE	2	5.7LX BRAVO	
11	10	14883	SCREW (3/8-16 X 1-1/8 IN.)	6	5.7LX BRAVO	
12	12	20572	WASHER	6	5.7LX BRAVO	
13	10	49845	SCREW (7/16-20 X 1 IN.)	6		
14	429	9521	CRANKSHAFT	1		
15	28	34466	KEY	2		