



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805439A 9	ELECTRICAL BOX	1		
1A		806762A 1	VELCRO KIT	1		
2		806611T	KNOCK MODULE	1		
3	11	64015	NUT	1		
4	89	96054	STARTER SOLENOID	1		
5	13	26995	LOCKWASHER (#8)	2		
6	11	26419	NUT (8-32)	2		
7	13	26992	LOCKWASHER (1/4")	2		
8	11	94330	NUT (1/4-20)	2		
9	12	35462	WASHER	2		
10	11	64015	NUT	2		
11	85	97861	INSULATOR	1		
12	88	11178	CIRCUIT BREAKER	1		
13	10	45862	SCREW	2		
14	11	61356	NUT	2		
15	13	26996	LOCKWASHER	2		
16	11	68219	NUT	2		
17		805615A 2	THUMB SCREW	1		
17A	10	24323	SCREW	3	ALPHA	
18	23	806981	SPACER	3	ALPHA	
18	23	92152	SPACER	3	BRAVO	
19	12	35462	WASHER	3		
20	11	64015	NUT	3		
21		<a href="#">806720T 3</a>	ELECTRONIC CONTROL MODUL	1		
22	10	54615	SCREW	4		
23	12	20533	WASHER	4		
26		805704	SPARE FUSE (15 AMP)	1		
26		805703	SPARE FUSE (10 AMP)	1		
27		805439T 3	ELECTRICAL COVER	1		