



| Parts List | | | | | | |
|------------|-------|-----------|-------------------------------|-----|---------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 860256A | 2 HOUSING ASSEMBLY-THERMOS | 1 | | |
| 2 | 22 | 32803 | PLUG-PIPE (3/8 IN.) | 2 | | |
| 3 | 27 | 806871 | GASKET-THERMOSTAT | 1 | | 2 |
| 4 | 27 | 53045 | 1 GASKET | 1 | | 2 |
| 5 | | 807252 | 2 THERMOSTAT (160 DEG.) | 1 | | |
| 6 | 23 | 806922 | SLEEVE | 1 | | |
| 7 | 10 | 98508 | SCREW (3/8-16 X 3 IN.) | 2 | | |
| 8 | 32 | 808033 | HOSE-THERMOSTAT HOUSING | 1 | | |
| 9 | 32 | 808032 | HOSE-HOSE EXTENDER TO TRA | 1 | | |
| 10 | 32 | 807694 | 40 HOSE-TRANSMISSION OIL COOL | 1 | | |
| 11 | 54 | 815504222 | CLAMP-HOSE | 6 | | |
| 12 | 32 | 87108 | HOSE-THERMOSTAT HOUSING | 1 | | |
| 13 | 54 | 815504232 | CLAMP | 2 | | |
| 14 | 32 | 806635 | 1 HOSE-THERMOSTAT HOUSING | 1 | | |
| 15 | 32 | 807697 | HOSE-THERMOSTAT HOUSING | 1 | | |
| 16 | 54 | 815504220 | CLAMP-HOSE | 4 | | |
| 17 | 54 | 47715 | CLIP | 1 | | |
| 18 | 11 | 29250 | NUT (5/16-24) | 1 | | |
| 19 | | 860315A | 1 EXTENDER-HOSE | 1 | | |
| 20 | 22 | 806608A | 1 PLUG-DRAIN | 1 | | |
| 21 | 25 | 806609 | QUAD RING | 1 | | 2 |
| 22 | | 48134 | BRACKET | 1 | DESIGN I | |
| 23 | 54 | 97862 | CLAMP | 1 | DESIGN I | |
| 24 | 10 | 54630 | SCREW (5/16-24 X 5/8 IN.) | 1 | DESIGN I | |
| 25 | 13 | 39107 | LOCKWASHER (5/16 IN.) | 1 | DESIGN I | |
| 26 | 11 | 22053 | NUT (5/16-24) | 1 | DESIGN I | |
| 27 | | 860418T | BRACKET | 1 | DESIGN II | |
| 28 | | 860417T | CLAMP | 1 | DESIGN II | |
| 29 | 12 | 35462 | WASHER | 1 | DESIGN II | |
| 30 | 11 | 72008 | NUT | 1 | DESIGN II | |
| - | 27 | 806871A96 | GASKET SET-OVERHAUL | 1 | CONTENTS INDICATED BY FOO | |