



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY	1		
2	16	814002	1 STUD (2-7/8")	1		
3		13051A	4 ACTUATING LEVER ASSEMBLY	1		
4	24	45599	1 SPRING	1		
5	10	13743	1 SHOULDER SCREW	1		
6	18	32857	1 COTTER PIN	1		
7	24	98880	1 SPRING	1		
8	12	56720	1 WASHER	1		
9	12	35462	3 WASHER	3		
10	11	13438	2 NUT	2		
11	16	96112	1 STUD	1		
12	11	63341	1 TEE NUT	1		
13		13898A	3 SHIFT LEVER ASSEMBLY	1		
14	10	13743	1 SHOULDER SCREW	1		
15	17	814001	1 SHOULDER PIN	1		
16	18	21071	1 COTTER PIN	1		
17	87	19752A	6 SWITCH ASSEMBLY	1		
18	10	30902	2 SCREW	2		
19		813995A	1 SPRING GUIDE ASSEMBLY	1		
20	10	65746	1 SCREW	3	USE WITH CAST IRON ELBOWS	
21	23	806981	3 SPACER	3	USE WITH STAINLESS STEEL E	
22	12	35462	3 WASHER	3	USE WITH STAINLESS STEEL E	
23	11	64015	3 NUT	3	USE WITH STAINLESS STEEL E	