



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		97257A	1 WATER TEMPERATURE SENDE	1		
1		49734A	1 WATER TEMPERATURE SENDE	OPT	(DUAL STATION)	4
2		815425	1 OIL PRESSURE SENDER	1		
2		37293	1 OIL PRESSURE SENDER	OPT	(DUAL STATION)	4
3	13	26996	2 LOCKWASHER	2		
4	11	68219	2 NUT	2		
5	22	805059	1 REDUCER	1		
6		805218T	1 COOLANT TEMPERATURE SENS	1		
7		806612T	1 KNOCK SENSOR	1		
8	22	806705	1 Y-FITTING	1		
9	22	36382	1 PIPE PLUG	1		
10		805592A	1 CONNECTOR	1	BRAVO ENGINES	
11	84	95084A	1 WIRE	1	BRAVO ENGINES	
12	88	79091	1 FUSE	1	BRAVO ENGINES	
13	84	95084A	1 WIRE	1	BRAVO ENGINES	
14		816492A	1 AUDIO WARNING SWITCH	1		
15		806816T	1 BRACKET/LIFTING EYE (REAR)	1		
16	10	98261	2 SCREW	2		
17		26079A	2 PLATE ASSEMBLY	1		
18	10	15001	4 SCREW	4		
19	87	805605A	1 PRESSURE SWITCH	1		
20	22	805328	1 ELBOW	1		

