



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A 1	HOUSING ASSEMBLY-THERMOS	1		
2	22	32803	PLUG-PIPE (3/8 IN.)	2		
3	27	806871	GASKET-THERMOSTAT	1		2
4	27	53045 1	GASKET	1		2
5		807252 2	THERMOSTAT (160 DEG.)	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW (3/8-16 X 1 IN.)	2		
8	32	808033	HOSE-THERMOSTAT HOUSING	1		
9	32	860089	HOSE-FUEL COOLER TO POWEF	1		
10	32	808044 1	HOSE-POWER STEERING COOLI	1		
11	32	17435 79	HOSE-SEA WATER PUMP TO DR	1		
12	54	815504222	CLAMP-HOSE	8		
13	32	87108	HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	860144	HOSE	1	THERMOSTAT HOUSING TO PC	
16	32	807697	HOSE	1	THERMOSTAT HOUSING TO ST	
17	54	815504220	CLAMP-HOSE	4		
18	54	47715	CLIP	1		
19	11	29250	NUT (5/16-24)	1		
20		807292T	COOLER-POWER STEERING OIL	1		
21		805546A 2	BRACKET-TRANSMISSION OIL C	1		
22		77223 3	PAD	1		
23	54	815504224	CLAMP	1		
24	10	816585	SCREW (5/16-18 X 7/8 IN.)	1		
-	27	75611A96	GASKET SET-ENGINE OVERHAU	1		