



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	849142A	1 HARNESS ASSEMBLY-Wiring	1		
2		26079A	2 PLATE KIT	1		
3	10	15001	SCREW (#8-16 x .875)	4		
4		848734	1 BRACKET	1	(Electrical Components Mount)	
5	88	11178	BREAKER-Circuit (50 AMP)	1		
6	13	26996	LOCKWASHER (#10)	2		
7	11	68219	NUT (#10-32)	2		
8	10	45862	SCREW (#10-32 x .875)	2		
9	11	61356	NUT (#10-32)	2		
10	89	818999A	2 SOLENOID ASSY-Starter	1		
11	25	818967	GROMMET	2		
12	23	818968	BUSHING	2		
13	12	29245	WASHER	2		
14	13	26992	LOCKWASHER (.250)	2		
15	10	76630	SCREW (.250-20 x 1.00)	2		
16	13	26995	LOCKWASHER (#8)	2		
17	11	26419	NUT (#8-32)	2		
18	13	26992	LOCKWASHER (.250)	2		
19	11	94330	NUT (.250-20)	2		
20		849363	SENDER ASSEMBLY	1	(Oil Temperature)	
21	13	26996	LOCKWASHER (#10)	3		
22	11	45076	NUT (#10-32)	3		
23	22	64013	REDUCER-Engine Block	1		
24		97257A	1 SENDER ASSY	1	(Water Temperature) (Thermostat I	
24		49734	SENDER ASSY	OPT	(Water Temperature) (Dual Engine	
25	10	88829	SCREW (#10-24 x .500)	4		
26		848191	1 BRACKET-Wire Harness	1		
27		815425	SENDER ASSEMBLY	1	(Oil Pressure)	
27		37293	SENDER ASSEMBLY	OPT	(Oil Pressure) (Dual Engine Models	
28		42600A	3 CONTROLLER ASSEMBLY	1		
29	12	30164	WASHER	2		
30	13	26996	LOCKWASHER (#10)	7		
31	10	41771	SCREW (#10-24 x .875)	2	(Non Driveline Models)	
31	10	35401	SCREW (#10 x 1.00)	2	(Driveline Models)	
32	10	62568	SCREW (#10-16 x .375)	1		
33	11	68219	NUT (#10-32)	4		
34	84	86322A	17 CABLE ASSEMBLY (Black)	1	(Non Driveline Models)	
35		807763T	BRACKET-Module Mounting	1		
36	10	806827	SCREW (#8-32 x .375)	6		
37		848821	2 MODULE-Ignition	1		
38		805442T	MODULE ASSEMBLY	1	(Speed Control)	