



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12675A 7	HOUSING ASSEMBLY-Flywheel	1		
2		88791	MOUNT-Rubber-Flywheel Housin	2		
3	23	99322	SPACER-Rubber Mount-Flywheel	2		
4	10	37612	SCREW	3	(.375-16 X 1.250)	
4	10	32132	SCREW	1	(.375-16 X 1.750)	
5	16	64066	STUD (2.750 Inches)-Flywheel Hoc	2		
6	11	32219	NUT (.375-16)-Flywheel Housing At	2		
7	13	35048	LOCKWASHER (.375)-Flywheel Ho	8		
8	12	856774	WASHER-Special (.375)-Housing S	1		
9	54	78945	J CLAMP-Flywheel Housing Stud	2		
10		818719A 3	COVER KIT	1	(STEEL) (SERIAL # 0F745195 TH 9	
10		807260A 2	COVER KIT	1	(PLASTIC) (SERIAL # 0K000001	
11	10	32773	SCREW	7	(.250-20 X .875) (STEEL COVER)	
11	10	45561	SCREW	2	(.250-20 X 1.120) (PLASTIC COVI	
12	84	62826A 6	CABLE ASSEMBLY	2	(Black)	
13	54	62494	CLIP-Water Hose	1		
14	12	20553	WASHER	6		
15	12	29245	WASHER	2	(PLASTIC COVER) (SERIAL # 0K	