



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A82	PUMP ASSEMBLY-Sea Water	1	(COMPLETE)	
NS	22	36382	PLUG-Pipe (.250-18)	2		
2	46	72774A89	BODY/IMPELLER KIT-Sea Water	1		
3	27	805215 1	GASKET-Cover To Outer Wear	1		
4	27	94914	GASKET-Body To Wear Plate	2		
5	47	59362 1	IMPELLER	1		
6	25	94288	RING-Quad-Pump Housing	1		
7		821707 1	COVER-Sea Water Pump	1		
8	10	39001	SCREW (.312-18 x 4.500)	5		
9	12	20084	WASHER	10		
10		94916	WEAR PLATE-Outer	1		
11	19	59504	PLUG-Impeller	1		
12		94576	WEAR PLATE-Inner	1		
13		818367A 1	HOUSING ASSEMBLY-Sea Water	1		
14	26	90562	SEAL-Oil-Sea Water Pump Sha	2		
15		818366A 1	SHAFT KIT-Sea Water Pump	1		
16		818745A 1	SLIP RING KIT	1		
17	12	89664	WASHER	1		
18	30	72961	BEARING-Ball-Sea Water Pump	2		
19	53	23720	RING-Retaining-Ball Bearing	1		
20	26	806930	SEAL-Oil-Sea Water Pump Sha	1		
21		818365 2	PULLEY	1	(BLUE)	9
22	10	79953A 2	SCREW ASSEMBLY-Plug	1		
23	25	805726	O RING	1		
24	13	39107	LOCKWASHER (.312)	1		
25	11	21908	NUT (.312-18)	1		
26		823185A2	BRACKET KIT-Sea Water Pump	1		9
27	10	66024	SCREW (.437-14 x 1.750)	3		
28	10	28782	SCREW (.375-16 x .875)	2		
29	13	26993	LOCKWASHER (.375)	2		
30	10	99204	SCREW (.437-14 x 1.00)	1		
31	43	818381 1	PINION/STUD	1		9
32		818380T	BUSHING	1		
33		818382	PULLEY	1		
34	11	817618	NUT (.437-20)	1		
35	57	69143T	V BELT	1		
36	12	27025	WASHER	1		
37		818379T	BRACKET-Idler	1		
38	12	45176	WASHER	3		