



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	22	32820	CONNECTOR	1	
2	32	823229A 3	HOSE ASSEMBLY (13.500 In.)	1	
3	54	815504104	CLAMP	1	
4		848578	VALVE	1	
5	25	811553	GROMMET	1	4
6		817116A 3	SUPERCHARGER ASSEMBLY	1	
7		847711 1	PULLEY-Upper Driven	1	
8	27	817118 1	GASKET-Intake To Supercharger	1	4
NS	22	32802 1	PLUG-Pipe (.125 Brass)	1	4.2
NS	22	36382	PLUG-Pipe (.250 Brass)	1	2
9	11	35814	NUT (.312-24)	6	
10	12	70132	WASHER	6	
11	16	848562	STUD (.375 x 1.650)	6	
12	54	64628 1	LIFTING EYE	2	
13	10	812567	SCREW (.375-16 x 1.625)	8	
13	10	815687	SCREW (.375-16 x 1.250)	7	
13	10	47432	SCREW (.375-16 x 2.00)	1	
14	12	45175	WASHER	16	
15		848582 1	MANIFOLD-Intake	1	
16	27	818188	GASKET-Intake Manifold	2	1.4
17		816073	SHIELD-Intake	1	
18	22	806242	CONNECTOR-By Pass	2	
19	54	815504412	CLAMP	2	
20	32	805987	HOSE-By Pass	1	
21	10	811574	SCREW (.375-16 x 1.750)	4	
22		811573	PUMP ASSEMBLY-Circulating Wat	1	
23	27	49110	GASKET-Water Pump	2	4
24		52349 1	PULLEY-Circulating Pump	1	
25	13	39107	LOCKWASHER (.312)	4	
26	10	47277	SCREW (.312-24 x .750)	4	
27	57	816034	V BELT-Alternator Drive	1	
28	57	817113	BELT-Serpentine	1	
29		811570	COVER ASSEMBLY-Timing Chain	1	
30	26	821947 1	SEAL-Oil	1	4
31	27	811572	GASKET	1	4
32	10	35366	SCREW (.250-20 x .562)	10	
33		811556	DAMPNER	1	1
34		821981 1	PULLEY-Crankshaft	1	
35	12	49103	WASHER	1	
36	13	14759	LOCKWASHER	1	
37	10	811559	SCREW	1	