



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	806964A 3	STARTER ASSEMBLY	1	(BRAVO PLUG-IN MODELS)	
2		NSS	ARMATURE	1		6
3		NSS	BRUSH HOLDER AND SPRING	1		6
4		NSS	FRAME	1		6
5		NSS	SCREW	2		6
6		NSS	BOLT-Thru	2		6
7		NSS	SHAFT AND GEAR	1		6
8		NSS	GASKET	1		6
9		NSS	GEAR	1		6
10		NSS	DRIVE	1		6
11		33291	COLLAR	1		
12	53	33290	RING-Retaining	1		
13		NSS	COLLAR-Thrust	1		6
14		809459	HOUSING-Drive	1		
15	23	814476	BEARING	1		
16		NSS	GROMMET	1		6
17		809463A 1	SOLENOID	1		
18		NSS	LEVER	1		6
19		NSS	SCREW	3		6