



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		817116A1	SUPERCHARGER KIT	1		
2		847711 1	PULLEY-Upper Driven	1		
3	27	817118 1	GASKET-Intake to Supercharger	1		14
4	11	28770	NUT (.312-24)	6		
5	12	70132	WASHER	6		
6	54	64628 1	LIFTING EYE	2		
7	10	812567	BOLT (.375-16 x 1.625)	8		
7	10	815687	BOLT (.375-16 x 1.250)	7		
7	10	47432	SCREW (.375-16 x 2.00)	1		
8	12	34931	WASHER	16		
9	16	33111	STUD	6		
10		817115	MANIFOLD-Intake	1		
11	27	818188	GASKET-Intake Manifold	2		14
12		816073	SHIELD-Oil Intake	1		
13	22	806242	CONNECTOR-Intake Pump/Intake	2		
14	54	815504412	CLAMP-By Pass Hose	2		
15	32	805987	HOSE-By Pass-Water Pump/Intake	1		
16	10	811574	SCREW (.375-16 x 1.750)-Water P	4		
17		811573	PUMP ASSEMBLY-Water	1		
18	27	49110	GASKET-Water Pump Mounting	2		14
19		52349	PULLEY-Water Pump (BLACK)	1		
19		52349 1	PULLEY-Water Pump (BLUE)	1		
20	57	816034	V BELT-Alternator Drive	1		
21	57	817113	BELT-Serpentine	1		
22	13	39107	LOCKWASHER (.312)-Water Pump	4		
23	10	47277	SCREW (.312-24 x .750)-Pulley to \	4		
24	27	54529	GASKET-Crankcase Cover	1	(S/N: 0D456000 - 0D725808)	14,5
24	27	811572	GASKET-Crankcase Cover	1	(S/N: 0D763746 - 0F348963)	14,6
25		66215	COVER ASSEMBLY-Crankcase	1	(S/N: 0D456000 - 0D725808)	5
25		811570	COVER ASSEMBLY-Crankcase	1	(S/N: 0D763746 - 0F348963)	6
26	26	821947 1	SEAL-Oil-Crankcase Cover	1		14
27	10	35366	SCREW (.250-20 x .562)-Crankcase	10		
28		59966	POINTER-Timing	1		
29		72605 1	DAMPER	1	(S/N: 0D456000 - 0D725808)	5
29		811556	DAMPER	1	(S/N: 0D763746 - 0F348963)	6
30		52181	PULLEY-Harmonic Balancer	1	(S/N: 0D456000 - 0D725808)	5
31		817112	PULLEY-Crankshaft (BLACK)	1	(S/N: 0D456000 TO 0D725808)	5
31		821981 1	PULLEY-Crankshaft (BLUE)	1	(S/N: 0D763746 - 0F348963)	6
32	12	49103	WASHER-Pulley and Balancer Scr	1		
33	13	14759	LOCKWASHER-Pulley and Harmor	1		
34	10	817125	SCREW (.500-20 x 4.00)	1	(S/N: 0D456000 - 0D725808)	5