



| Parts List | | | | | | |
|------------|-------|-----------|----------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 84 | 849912T 1 | HARNESS ASSEMBLY-EFI | 1 | | |
| NS | 88 | 804638 | FUSE-Mini | 1 | (Red - 10 AMP) | |
| NS | 88 | 804639 | FUSE-Mini | 2 | (Blue - 15 AMP) | |
| NS | | 807057T | RELAY | 2 | (Ignition And Fuel Pump) | |
| NS | 54 | 804352 | CLIP-Hold Down | 2 | (Fuse Case) | |