



2179

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		849297T 1	BRACKET-Idler Pulley	1	(Non Power Steering Models)	
2	12	856774	WASHER	2		
3	10	840244	SCREW (.375-16 x 3.375)	2		
4	10	821301 30	SCREW (M10 x 30)	1		
5		849296T	PULLEY	1	(Power Steering Models)	
5		849296T	PULLEY	2	(Non Power Steering Models)	
6	54	62494	CLIP-Hose	1	(Cooler To Circulating Pump)	
7		857006A 3	ALTERNATOR KIT (Blue)	1	(Serial # 0L601000 Thru 0L602090)	
7		875285T 2	ALTERNATOR ASSEMBLY (Blue)	1	(Serial # 0L306696 Thru 0M05325)	
8		849043T	PULLEY-Alternator (Blue)	1	(Serial # 0L601000 Thru 0L602090)	
8		842421T	PULLEY-Alternator (Blue)	1	(Serial # 0L306696 Thru 0M05325)	
9	10	95802	SCREW (.375-16 x 2.750)	1	(Serial # 0L601000 Thru 0L602090)	
9	10	849397	SCREW (.375-16 x 3.250)	1	(Serial # 0L306696 Thru 0M05325)	
10	12	856774	WASHER	3		
11	12	824451	WASHER-Thrust	1	(For Pulley) (.610 ID x .890 OD x .1)	
11	12	856774	WASHER-Thrust	1	(For Pulley) (.406 ID x .750 OD x .1)	
12	11	826833 6	NUT (M6)	1	(For Pulley)	
13	10	69267	SCREW (.312-18 x 1.750)	1		
14	12	814806	WASHER	2		
15	11	67980	NUT (.312-18)	1		
16	12	846673	WASHER	1		
17	11	40138 6	NUT (M6)	1		
18	50	<a href="#">806964A 3</a>	STARTER ASSEMBLY	1	(See Starter Assembly Section For	
19	88	79023A91	FUSE ASSEMBLY (90 AMP)	1		
20	85	79695	BOOT-Insulator	1		
21	11	826709109	NUT (.250-28)	1		
22	13	39107	LOCKWASHER (.312)	1		
23	11	40063 5	NUT (M8)	1		
24	11	40021 1	NUT (M5)	1		
25	13	26996	LOCKWASHER (#10)	1		
26	10	805343 2	SCREW (.375-16 x 4.330)	2		
27	15	817272 1	SHIM (Special)	1		
28	10	94247	SCREW (.375-16 x .750)	1		
29		845117	BUSHING	1		
30	11	817618	NUT (.437-20)	1		
31	10	843575	SCREW (.375-16 x 4.00)	1		
32		845124T 1	BRACKET-Tensioner	1		
33	43	818381 2	PINION/STUD	1		
34	16	57920 3	STUD (.437-20 x 2.06)	2		
35	11	817618	NUT (.437-20)	4		
36	12	45176	WASHER	4		