



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		38420	EXHAUST MANIFOLD	1		
2	22	38565	FITTING, EXHAUST MANIFOLD -	1		
3	32	38306	HOSE, WATER INLET - EXHAUST	1		
4	54	35830	CLAMP, WATER INLET HOSE TO	1		
5	54	35830	CLAMP, WATER INLET HOSE TO	1		
6	22	33060	NIPPLE, EXHAUST MANIFOLD - E	1		
7	32	38437	HOSE, BLEED - EXHAUST MANIF	1		
8	54	38863	CLAMP, BLEED HOSE TO EXHAU	1		
9	54	20386	CLAMP, BLEED HOSE TO CYLINC	1		
10	22	38831	ELBOW, CYLINDER BLOCK TEE -	1		
11	22	28624	TEE, CYLINDER BLOCK - BLEED	1		
12	22	32802	PLUG, CYLINDER BLOCK DRAIN	1		
13		38421	COVER, EXHAUST MANIFOLD (FF	1		
14	27	38561	GASKET, FRONT EXHAUST MAN	1	(Part of 27-37097A1)	
15	10	35388	SCREW, FRONT COVER TO EXH.	4		
16	22	32715	ELBOW, FRONT COVER	1		
17	32	38436	HOSE, THERMOSTAT CONTAINE	1		
18	54	38819	CLAMP, HOSE TO EXHAUST MAP	1		
19	54	38819	CLAMP, HOSE TO THERMOSTAT	1		
20	22	32715	ELBOW, THERMOSTAT CONTAIN	1		
21		38418	CONTAINER, THERMOSTAT	1		
22	27	38555	GASKET, THERMOSTAT CONTAI	1		
23	10	38521	SCREW, THERMOSTAT CONTAIN	6		
24	54	33361	CLIP, WIRING HARNESS - THER	1		
25		35884	THERMOSTAT	1		
26		38419	COVER, THERMOSTAT	1		
27	27	38556	GASKET, THERMOSTAT COVER	1		
28	10	21077	SCREW, COVER TO THERMOST.	2		
29	22	32715	ELBOW, THERMOSTAT COVER	1		
30	32	38435	HOSE, THERMOSTAT COVERE T	1		
31	54	38819	CLAMP, HOSE TO THERMOSTAT	1		
32	54	38819	CLAMP, HOSE TO INTAKE MANIF	1		
33		38424	INTAKE MANIFOLD	1		
34	22	33066	CONNECTOR, INTAKE MANIFOLD	2		
35	27	37097	GASKET, INTAKE AND EXHAUST	1	(Part of 27-37097A1)	
36	16	37084	STUD, INTAKE AND EXHAUST M	4		
37	16	37087	STUD, EXHAUST MANIFOLD TO	2		
38	12	20103	WASHER, SPACER - CYLINDER H	4		
39	12	37086	WASHER, CYLINDER HEAD STU	6		
40	11	37085	NUT, CYLINDER HEAD STUD	6		
41		38422	COVER, EXHAUST MANIFOLD (R	1		