



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	429	808161	CRANKSHAFT	1	INCLUDES ALL STANDARD BEA	
2	222	805822	FLYWHEEL	1		
3	43	808099	RING GEAR	1		
4	10	805766	SCREW	9		
5	12	805787	WASHER	9		
9	23	808153	BEARING SET (STANDARD)	4		
9	23	808154	BEARING SET (.010 U.S.)	AR		2
9	23	808155	BEARING SET (.020 U.S.)	AR		2
9	23	808156	BEARING SET (.030 U.S.)	AR		2
10	23	808157	BEARING SET-CENTER (STANDA	1		
10	23	808158	BEARING SET-CENTER (.010 U.S	AR		2
10	23	808159	BEARING SET-CENTER (.020 U.S	AR		2
10	23	808160	BEARING SET-CENTER (.030 U.S	AR		2
11	28	808109	KEY	1		
12	43	808167	CRANKSHAFT GEAR	1		
13		808281	DAMPER	1		
14	23	805832F 2	SPACER	1		
15	10	808092	SCREW	1		
16	12	808113	WASHER	1		
17		805800	PULLEY	1		
18		805801	PULLEY	1		
19	10	805761	SCREW	4		
20	12	805787	WASHER	4		
-		806245A 2	ENGINE COUPLER ASSEMBLY	1	2 STAGE COUPLER	
21		806245T	COUPLER PLATE	1	2 STAGE COUPLER	
22	10	806383	SCREW	12	2 STAGE COUPLER	
23	24	806395A 1	SPRING	2	2 STAGE COUPLER	
23	24	806270A 1	SPRING	2	2 STAGE COUPLER	
24		806271	SPRING RETAINER	8	2 STAGE COUPLER	
25		806246A 1	BEARING SUPPORT	1	2 STAGE COUPLER	
26	30	818942T	BALL BEARING	1	2 STAGE COUPLER	
27	53	818944	RETAINING RING	1	2 STAGE COUPLER	
28		806531	RETAINER PLATE	1	2 STAGE COUPLER	
29		806268T	COUPLER PLATE	1	2 STAGE COUPLER	
30		821625	SNUBBER	6	2 STAGE COUPLER	
31	10	806396	SCREW	6	2 STAGE COUPLER	
32		805684A 2	COUPLER ASSEMBLY	1	2 STAGE COUPLER	
33	22	74036	GREASE FITTING	1	2 STAGE COUPLER	
34	10	47461	SCREW	6	2 STAGE COUPLER	
35	10	73657	SCREW	6	2 STAGE COUPLER	
36	12	12028	WASHER	6	2 STAGE COUPLER	