



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805868	HEAT EXCHANGER - W/DECALS	1		
2	22	36382	PIPE PLUG	2		
3	36	808108	FILLER CAP	1		
4		808112	ZINC ANODE	1		
5		805862	BRACKET	2		
6		805863	STRAP	2		
7	10	805768	SCREW (4")	2		
8	10	806249	SCREW (6-1/2")	1		
8	10	806155	SCREW (7-1/2")	1		
9	12	805787	WASHER	8		
10	11	805781	NUT	4		
11	32	805897	HOSE	1		
12	54	815504336	CLAMP	2		
13	84	86322A22	GROUND WIRE	1		
14	32	805894	HOSE	1		
15	54	815504232	CLAMP	2		
16	32	805750	HOSE	1		
17	54	815504220	CLAMP	4		
18	32	805755	HOSE	1		
19		806918	BRACKET	1		
20	16	70236	STUD	2		
21	54	814858	CLAMP	2		
22	12	805792	WASHER	2		
23	11	806134	NUT	2		
24		805891	OIL COOLER	1		
25		808112	ANODE	1		
26	22	97368	ELBOW	2		
27		805826F 2	HOUSING	1		
28	27	805799	GASKET	1		
29	10	805774	SCREW (3")	1		
29	10	805783	SCREW (1-3/4")	1		
30	12	805792	WASHER	1		
31		805886	SUPPORT (PORT)	1		
32		805887	SUPPORT (STARBOARD)	1		
33	12	805792	WASHER	2		
34	11	63078	NUT	2		
35	37	805600	DECAL	1		
36	23	72057	SPACER	2		
37		806308	LIFTING EYE	1		
38	10	805763	SCREW	1		
39	12	805787	WASHER	1		