



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		861096T	BRACKET-ELECTRICAL COMPON	1		
1		861715T 1	BRACKET-ELECTRICAL COMPON	1	(S/N 0L086001 AND UP) MEFI-3	1
2		861535T	MODULE ASSEMBLY-SPARK CO	1		
3	12	20533	WASHER	2		
4	11	805562	NUT-LOCK	2		
5	89	96158T	SOLENOID-STARTER	1		
6	10	28635	SCREW (1/4-20 X 5/8 IN.)	1		
7	16	805459	STUD	2		
8	13	26992	LOCKWASHER (1/4 IN.)	2		
9	11	94330	NUT (1/4-20)	2		
10	13	26996	LOCKWASHER (#10)	2		
11	11	68219	NUT (#10-32)	2		
12	85	97861	INSULATOR-STARTER SOLENOI	1		
13	88	806950	BREAKER-CIRCUIT (50 AMP)	1		
14	10	68513	SCREW (#10-32 X 3/8 IN.)	2		
15	13	26996	LOCKWASHER (#10)	2		
16	10	57583	SCREW (#8-32 X 3/8 IN.)	2		
17		861736R 1	MODULE-ECM	1		
17		861736R 1	MODULE-ECM	1		
17		861736R 1	MODULE-ECM	1		
17		861736R 1	MODULE-ECM	1		
17		861720T 2	MODULE-ECM	1	(S/N 0L086001 AND UP) MEFI-3	1
18	10	76596	SCREW (1/4-20 X 1-1/4 IN.)	2		
18	10	28636	SCREW (1/4-20 X 3/4)	3	(S/N 0L086001 AND UP) MEFI-3	1
19	12	20533	WASHER	2		
20	10	29198	SCREW (5/16-18 X 7/8 IN.)	1		
21		805704	FUSE (15 AMP)	1		
21		805703	FUSE (10 AMP)	1		
22		42600A 3	CONTROLLER-MERCATHODE	1		
23	12	56681	WASHER	2		
24	11	46438	NUT (#10-32)	2		
25	11	68219	NUT (#10-32)	4		
26	10	62568	SCREW	1		
27		807057T	RELAY-FUEL PUMP	1		
27		807057T	RELAY-IGNITION SYSTEM	1		