



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A 1	HOUSING ASSEMBLY-THERMOSTAT	1		
2	22	32803	PLUG-PIPE (3/8 IN.)	2		
3	27	806871	GASKET-THERMOSTAT	1		3,4
4	27	53045 1	GASKET-THERMOSTAT HOUSING	1		3,4
5		807252 2	THERMOSTAT	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW (3/8-16 X 1 IN.)	2		
8	32	807407	HOSE-THERMOSTAT HOUSING	1		
9	32	808052	HOSE-COOLER TO COOLER	1	(USE WITH 10 IN. ENGINE OIL C	
9	32	807406	HOSE-COOLER TO COOLER	1	(USE WITH 13 IN. ENGINE OIL C	
10	32	807404	HOSE-TRANSMISSION OIL COOL	1		
11	32	821415	HOSE-SEAWATER PUMP INLET	1		
12	54	815504222	CLAMP	8		
13	32	89718 1	HOSE-THERMOSTAT HOUSING	1		
14	54	815504232	CLAMP	2		
15	32	97385 3	HOSE-THERMOSTAT HOUSING	1		
16	32	807201	HOSE-THERMOSTAT HOUSING	1		
17	54	815504220	CLAMP	4		
18	54	806616	CLAMP-HOSE SUPPORT	1		
19		77054	STA-STRAP (14-1/2 IN.)	1		
20		807479T	COOLER-TRANSMISSION OIL	1		
21		807402T	BRACKET-OIL COOLER	1		
22		807445T	CLAMP	1		
23	12	35462	WASHER	1		
24	11	72008	NUT (1/4-20)	1		
25	10	86750	SCREW (5/16-18 X 5/8 IN.)	1		
26	13	39107	LOCKWASHER (5/16 IN.)	1		
27		805135	COUPLER-HOSE	1		
-	27	805396A95	GASKET SET-OVERHAUL	1	(7.4L)	
-	27	805396A92	GASKET SET-OVERHAUL	1	(8.2L)	