



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		802565	COVER-ROCKER	2		
2	36	802566T	CAP-OIL FILL	2		
3	27	811588	GASKET-ROCKER COVER	2		4
4	10	811589	BOLT (1/4-20 X 5/8 IN.)	14		
5		852003	PUSH ROD	8	(INTAKE)	
5		852004	PUSH ROD	8	(EXHAUST)	
6		814506	VALVE-EXHAUST	8	(STANDARD)	
6		814507	VALVE-EXHAUST	AR	(.015 O.S.)	3
7		49134	VALVE-INTAKE	8	(STANDARD)	
8		845707	GUIDE-PUSH ROD	8		
9		850464	CAP-INTAKE VALVE	8		
10		850463	ROTATOR-EXHAUST VALVE	8		
11	26	811545	SEAL-VALVE	16		4
12	24	850465	SPRING-VALVE	16		
13	28	54530	KEY-ROCKER	32		
14		850471	ARM-ROCKER	16		
15		850472	BALL UNIT	16		
16	10	811593	BOLT-ROCKER ARM	16		
17	938	802743	HEAD ASSEMBLY-CYLINDER	2		
18	27	850470	GASKET-CYLINDER HEAD	2		4
19	10	49106	BOLT (7/16-14 X 2 IN.)	8		
20	10	49105	BOLT (7/16-14 X 4-1/16 IN.)	24		
21	36	861124	TUBE-OIL FILL	1		
22	25	29439	O-RING	1		
23	25	811553	GROMMET-PCV HOLE	1		
24		802748	VALVE-PCV	1		
25	32	802749	TUBE-PCV	1		
26	22	802750	ELBOW-BREATHER	1		
-	27	802567A98	GASKET SET-ENGINE OVERHAU	1		