



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		818383T	FUEL PUMP	1		
2	27	34213	GASKET	1		3
3	10	34354	SCREW	2		
4	13	35048	LOCKWASHER	2		
5	22	43276	FITTING (90 DEGREES)	2		
6		89876A 3	BASE ASSEMBLY	1		
7	22	32561	PIPE PLUG	2		
8	22	816133 1	FITTING	1		
9	11	29250	NUT	2		
10	35	807172	FUEL FILTER	1		
11	22	42897	FITTING (STRAIGHT)	1		
12	32	818385T	FUEL LINE-FUEL FILTER TO FUE	1		
13	32	807079T	FUEL LINE-FUEL PUMP TO VST	1		
14		805556T 1	BRACKET	1		
15	32	73815 67	HOSE-FUEL PUMP TO THROTTL	1		
-	27	805396A95	GASKET SET	1		