



2065

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	808011A 1	STARTER ASSEMBLY	1		
2	10	47462	SCREW, (.437-14 x 1.250)	2		
3	11	15874	NUT, (M10)	1		
4	13	40024 7	LOCKWASHER, (M8)	1		
5	11	40021 1	NUT, (M5)	1		
6	13	26396	LOCKWASHER, (#10)	1		
7	88	79023A91	FUSE ASSEMBLY, 90 Ampere	1		
8	11	826711 9	NUT, (.250-28)	1		
9	85	79695	BOOT, Insulator - Black, Boot	1		
10		863077I	ALTERNATOR ASSEMBLY, Black	1		
11	10	824459110	SCREW, (M8 x 110)	1		
12	11	40136 8	NUT, (M8)	1		
13		863855T	BRACKET, Alternator	1		
14	10	40108120	SCREW, (M10 x 120)	1		
15		862353A 1	ADJUSTMENT ASSEMBLY, Belt	1		
16		NSS	NOT SOLD SEPARATE, Screw-E	1		
17		NSS	NOT SOLD SEPARATE, Nut-Jar	1		
18	10	40011151	SCREW, (M8 x 35)	1		
19	10	40108 35	SCREW, (M10 x 35)	1		
20	11	40021 2	NUT, (M6)	2		
21		863860T	BRACKET, Belt Tensioning	1		
22	10	40108 70	SCREW, (M10 x 70)	2		
23	13	32993	LOCKWASHER, (.437)	2		
24	57	863876 2	BELT, Serpentine	1		