



5168

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66418T	BRACKET, Front	2	(FRONT)	
2	10	68101	SCREW, (.375-16 x 1.375)	2		
3	16	805357	STUD, (.375-16 x 2.130)	4		
4	10	37269	SCREW, (.437-14 x 2.00)	2		
5	13	32993	LOCKWASHER, (.437)	2		
6	11	29553	NUT, (.437-14)	2		
7		66166A 4	TRUNNION	2		
8	13	68102	LOCKWASHER, (.750)	2		
9		66284A 2	BASE ASSEMBLY	2	(FRONT)	
10	11	20739	NUT, (.750-16)	2		
11	14	66658	TAB WASHER	2		
12	11	20739	NUT, (.750-16)	2		
13	10	40097 60	SCREW, (M12 x 60)	4		
14	10	57357	SCREW, (.437-13 x 2.250)	2		
15		805496T	BRACKET	1	(PORT) DOWN ANGLE TRANSM	
15		805496T 1	BRACKET	1	(STARBOARD) DOWN ANGLE TI	
15		807724T	BRACKET	1	(PORT) V-DRIVE TRANSMISSIO	
15		807725T	BRACKET	1	(STARBOARD) V-DRIVE TRANSI	
16	13	32993	LOCKWASHER, (.437)	2		
17	11	29553	NUT, (.437-14)	2		
18		66166A 4	TRUNNION	2		
19	13	68102	LOCKWASHER, (.750)	2		
20		816326A 2	BASE ASSEMBLY	2	(REAR)	
21	11	816331	NUT, (.750-16)	2		
22	14	66658	TAB WASHER	2		
23	11	20739	NUT, (.750-16)	2		