



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		818383T	PUMP-FUEL	1		
2	27	34213	GASKET-FUEL PUMP	1		3,4
3	10	34354	SCREW (3/8-16 X 1-1/2 IN.)	2		
4	13	35048	LOCKWASHER (3/8 IN.)	2		
5	22	43276	FITTING-ELBOW (90 DEG.)	2		
6		89876A 3	BASE ASSEMBLY	1		
7	22	32561	PLUG-PIPE (1/4-18)	2		
8	22	816133 1	FITTING	1		
9	11	35814	NUT (5/16-24)	2		
10	35	807172	FILTER-FUEL/WATER SEPARATI	1		
11	22	42897	FITTING (STRAIGHT)	1		
12	32	805637T	FUEL LINE-FUEL FILTER TO FUE	1		
13	32	807079T	FUEL LINE-FUEL PUMP TO VST	1	(USE W/O FUEL COOLER)	
13	32	807732T 3	FUEL LINE-FUEL PUMP TO VST	1	(USE WITH FUEL COOLER)	
14		805556T 1	BRACKET-FUEL FILTER BASE	1		
15	32	73815 67	TUBING-FUEL PUMP TO T-FITTI	1		
16	54	806617	CLAMP-FUEL LINE	1		
17	22	46982	FITTING-ELBOW (90 DEG.) (INLE	1		
-	27	805396A95	GASKET SET-OVERHAUL	1	(7.4L)	
-	27	805396A92	GASKET SET-OVERHAUL	1	(8.2L)	