



A = FROM TRANSMISSION OIL COOLER OUTLET

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		18900A 1	TRANSMISSION	1	(1.5:1 RATIO)	
1		18901A 1	TRANSMISSION	1	(2.0:1 RATIO) IN-LINE TRANSMISSION	
1		806729A 2	TRANSMISSION	1	(2.5:1 RATIO)	
1		806730A 2	TRANSMISSION	1	(2.8:1 RATIO) IN-LINE TRANSMISSION	
1		814437A 1	TRANSMISSION	1	(1.5:1 RATIO) V-DRIVE TRANSMISSION	
1		814438A 1	TRANSMISSION	1	(2.0:1 RATIO) V-DRIVE TRANSMISSION	
1		814439A 1	TRANSMISSION	1	(2.5:1 RATIO) V-DRIVE TRANSMISSION	
2	16	805259	STUD	4	V-DRIVE TRANSMISSION	
3	12	22248	WASHER	4	IN-LINE TRANSMISSION (630) &	
4	11	34933	NUT (7/16-20)	4	V-DRIVE TRANSMISSION	
5	10	47462	SCREW (7/16-14 X 1-1/4 IN.)	2	V-DRIVE TRANSMISSION	
6	13	32993	LOCKWASHER (7/16)	2	V-DRIVE TRANSMISSION	
2	16	57933	STUD	6		
3	12	79552	WASHER	6	IN-LINE TRANSMISSION (800)	
4	11	13439	NUT (7/16-20)	6		
7		79476A 1	FLANGE ASSEMBLY (1 IN.)	OPT		8
7		79476A 2	FLANGE ASSEMBLY (1-1/8 IN.)	OPT		8
7		79476A 3	FLANGE ASSEMBLY (1-1/4 IN.)	OPT		8
7		79476A 4	FLANGE ASSEMBLY (1-3/8 IN.)	OPT		8
7		79476A 5	FLANGE ASSEMBLY (1-1/2 IN.)	OPT		8
7		79476A 6	FLANGE ASSEMBLY (1-3/4 IN.)	OPT		8
7		79476A 7	FLANGE ASSEMBLY (2 IN.)	OPT		8
8	10	60171	SCREW-FLANGE (3/8-16 X 1-1/2)	2		
8	10	60169	SCREW-FLANGE (3/8-16 X 3/4)	2		
9	10	805159	SCREW-FLANGE (7/16-20 X 1-1/2)	4		
10	13	32993	LOCKWASHER (7/16 IN.)	4		
11	11	22024	NUT (7/16-20)	4		
12	87	813708	SWITCH-TEMPERATURE	1		
13	32	807416	HOSE-OIL (FROM OIL COOLER)	1	USE WITH SIDE MOUNTED OIL COOLER	
14	22	93190	CONNECTOR	1	USE WITH SIDE MOUNTED OIL COOLER	
15	32	807414	HOSE-OIL (TO OIL COOLER)	1	USE WITH SIDE MOUNTED OIL COOLER	
16	22	807272	ADAPTOR	1	USE WITH SIDE MOUNTED OIL COOLER	
17	32	805478 1	HOSE-OIL (FROM OIL COOLER)	2	USE WITH REAR MOUNTED OIL COOLER	
18		806238	BRACKET-SHIFT LINKAGE	1		
19	10	40001124	SCREW (M8-1.25 X 14)	2		
20	13	40024 7	LOCKWASHER (M8)	2		
21	16	97477A 3	STUD KIT	2		