



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		90747A21	DISTRIBUTOR ASSEMBLY	1	
2		16457A 4	CAP	1	
3	10	90926	SCREW	4	
4	27	98242 1	GASKET	1	
5		13524A 5	ROTOR/SENSOR WHEEL	1	
11	87	91019A 3	SENSOR ASSEMBLY	1	
12	10	66686	SCREW (1")	1	
12	10	72202	SCREW (1-1/4")	1	
13	43	813776 1	DRIVE GEAR	1	
14	17	47617	PIN	1	
15	23	90915	BUSHING	2	
16	27	34486 3	GASKET	1	3
17		52185	CLAMP	1	
18	10	11976	SCREW	1	
19	13	26996	LOCKWASHER	2	
20	11	68219	NUT	2	
21	84	816608A61	SPARK PLUG WIRE KIT	1	
23	33	59571	SPARK PLUG	8	
24		54676	RETAINER (2 WIRE)	2	
25		32783	RETAINER (3 WIRE)	2	
27	392	7803A 4	IGNITION COIL	1	
28		77294T	BRACKET	1	
29	10	41408	SCREW (1-1/2")	1	
30	12	30164	WASHER	2	
31	13	26996	LOCKWASHER	2	
32	11	68219	NUT	2	
33	10	59645	SCREW (3/4")	2	
34	13	39107	LOCKWASHER	2	
35	12	20084	WASHER	2	
36	16	90096A 1	STUD ASSEMBLY	2	
37	54	72821	RETAINER	2	
38	10	98260	SCREW	2	
39	13	35048	LOCKWASHER	2	