

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		814624A	FUEL PUMP	1		
2	27	34213	GASKET	1		3
3	10	37612	SCREW (1-1/4")	2		
4	13	35048	LOCKWASHER	2		
5		35377	PUSH ROD	1		
6		89876A	BASE	1		
7	22	36382	PIPE PLUG	3		
8	10	26066	SCREW	2		
9	11	35814	NUT	2		
10	35	60494	FUEL FILTER	1		
11	22	33821	CONNECTOR	2		
12	32	814884T	FUEL LINE, FILTER TO PUMP	1		
13	32	814885T	FUEL LINE, PUMP TO CARBURE	1		
13	32	818160T	FUEL LINE, PUMP TO CARBURE	1		
14	32	73815 63	HOSE, FUEL PUMP TO CARBURE	1		
15	22	93385	ELBOW	1		

