



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	847722A	1 HARNESS ASSEMBLY-Wiring	1		3
2		26079A	2 PLATE KIT	1		
3	10	15001	SCREW (#8-16 x .875)	4		
4		847676	1 BRACKET-Mount (.375 Holes)	1		
5	88	11178	BREAKER-Circuit (50 AMP)	1		
6	13	26996	LOCKWASHER (#10)	2		
7	11	68219	NUT (#10-32)	2		
8	10	45862	SCREW (#10-32 x .875)	2		
9	11	61356	NUT (#10-32)	2		
10	89	818999A	2 SOLENOID ASSEMBLY-Starter	1		
11	25	818967	GROMMET	2		
12	23	818968	BUSHING	2		
13	12	29245	WASHER	2		
14	13	26992	LOCKWASHER (.250)	2		
15	10	76630	SCREW (.250-20 x 1.00)	2		
16	13	26995	LOCKWASHER (#8)	2		
17	11	26419	NUT (#8-32)	2		
18	13	26992	LOCKWASHER (.250)	2		
19	11	94330	NUT (.250-20)	2		
20		13611	SENDER UNIT-Oil Temperature	1		
21	13	26996	LOCKWASHER (#10)	1		
22	11	45076	NUT (#10-32)	1		
23	22	42277	FITTING	1		
24		97257A	1 SENDER ASSY-Water Temperature	1		
24		49734A	1 SENDER ASSY-Water Temperature	OPT		3,6
25	13	26996	LOCKWASHER (#10)	1		
26	11	45076	NUT (#10-32)	1		
27		815425	SENDER ASSEMBLY-Oil Pressure	1		
27		37293	SENDER ASSEMBLY-Oil Pressure	OPT		6
28	13	26996	LOCKWASHER (#10)	1		
29	11	45076	NUT (#10-32)	1		
30	22	64013	REDUCER	1		
31	54	78945	J CLIP-Harness To Mount	1		
32		817509T	MODULE ASSEMBLY-Ignition	1		
33	12	29245	WASHER	2		
34	11	56374	NUT (.250-20)	3		
35	84	62826A	6 CABLE ASSEMBLY (Black)	1		
36	13	21272	LOCKWASHER (.250 Internal)	1		
37		823755A	2 OVERSPEED ASSEMBLY	1		
38	12	30164	WASHER	2		
39	12	26996	LOCKWASHER (#10)	2		