



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		847704A 1	HOUSING ASSEMBLY-Thermostat	1		
2	22	36373	PLUG-Pipe (.375-18)	1		
3	16	847742	STUD-By Pass Valve	1		
4	30	98475	BALL-Nylon	2		
5	24	75533	SPRING	2		
6	11	29488	NUT (#10-32)	2		
7		59137 1	THERMOSTAT	1		
8	10	30206	SCREW (.375-16 x 1.00)-Cover To	2		
9	12	37828	WASHER	2		
10	32	847707A 5	HOSE ASSEMBLY (24.00 In.) -Hou	1	(STARBOARD)	
11	32	847707A 4	HOSE ASSEMBLY (22.00 In.) -Hou	1	(PORT)	
12	32	818361	HOSE-Tube To Thermostat Housin	1		
13	54	18076 6	CLAMP	AR		4
14	32	822525	HOSE-Thermostat Housing To Purr	1		
15	54	18076 8	CLAMP	2		
16	32	17435 65	HOSE-Pickup To Pump	1		
17	32	53461 70	HOSE (48.00 In.)-Pump To Trans C	1		
18	32	816504	HOSE-Trans Cooler To Engine Coo	1		
19	32	12818	HOSE-Engine Cooler To Connector	1		3
20	22	13177	TUBE-Connector	1	(NON POWER STEERING)	
21	32	847707A 3	HOSE ASSEMBLY -Cover To Mani	1	(18.00 IN.) (STARBOARD)	
21	32	847707A 2	HOSE ASSEMBLY -Cover To Mani	1	(16.00 IN.) (PORT)	
22	25	20826	O RING	1		5
23	12	20086	WASHER-Housing To Manifold	3		
24	10	34353	SCREW (.375-16 x 1.00)-Housing T	3		
25		847706 1	COVER-Thermostat (Black)	1		
26	27	818364	GASKET-Thermostat	1		5
.	27	822740A 3	GASKET SET-Engine Overhaul	1		