



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		54100A 5	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 00000000-03975694	
1		54099A 5	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 00000000-03975694	
2	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 00000000-03975694	
3	22	48118	PLUG, EXHAUST MANIFOLD	2	SERIAL 00000000-03975694	
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2	SERIAL 00000000-03975694	
5	10	37612	SCREW, EXHAUST MANIFOLD TI	16	SERIAL 00000000-03975694	
5A	13	35048	WASHER, EXHAUST MANIFOLD	16	SERIAL 00000000-03975694	
1		65604A 4	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 03975695-09999999	
1		65603A 4	EXHAUST MANIFOLD ASSEMBLY	1	SERIAL 03975695-09999999	
2	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03975695-09999999	
4	22	32802	PLUG, PIPE - EXHAUST MANIF	2	SERIAL 03975695-09999999	
5B	16	49545	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03975695-09999999	
5B	16	6547	STUD, EXHAUST MANIFOLD TI	8	SERIAL 03975695-09999999	
5C	13	35048	WASHER, EXHAUST MANIFOLD	16	SERIAL 03975695-09999999	
5D	11	49838	NUT, EXHAUST MANIFOLD STI	16	SERIAL 03975695-09999999	
6	27	54566	GASKET, EXHAUST MANIFOLD T	2	SERIAL 00000000-00166999	
6	27	73866	GASKET, EXHAUST MANIFOLD T	2	SERIAL 00467000-09999999	2,3
7	54	54509	EYE, LIFTING - EXHAUST MANIF	2		
8	10	26801	SCREW, LIFTING EYE ATTACHIN	4	SERIAL 00000000-00324667	
8	10	26801	SCREW, LIFTING EYE ATTACHIN	2	SERIAL 03245668-03465227	
8	10	27165	SCREW, LIFTING EYE ATTACHIN	2	SERIAL 03975695-09999999	
8		1026801	SCREW, LIFTING EYE ATTACHIN	4	SERIAL 03465228-09999999	
9		60252	END CAP/CONNECTOR, EXHAUS	4		
10	27	48043	GASKET, END CAP/CONNECTOR	4		2
11	10	35386	SCREW, END CAP/CONNECTOR	12		
12	10	53016	SCREW, END CAP/CONNECTOR	4		
13	10	31984	SCREW, END CAP/CONNECTOR	2		
14		60426A 1	EXHAUST ELBOW ASSEMBLY	2	SERIAL 00000000-04612109	
14		76351A 1	EXHAUST ELBOW ASSEMBLY	2	SERIAL 04612110-09999999	
15	22	33198	PLUG, EXHAUST ELBOW	8		
16	32	58616A 1	TUBE ASSEMBLY, WATER SEF	2	SERIAL 00000000-04612109	
17	22	32802	PLUG, PIPE - EXHAUST ELBOW	2		
18	27	52076	GASKET, EXHAUST ELBOW TO E	4		2
19		60207	PLATE, EXHAUST ELBOW TO EX	2		
20	22	45084	FITTING, HOSE - EXHAUST ELBC	2		
21	13	37459	LOCKWASHER, EXHASUT ELBO\	8		
22	11	49838	NUT, EXHAUST ELBOW TO EXH	8		
23		59824	ELBOW, EXHAUST	2	SERIAL 00000000-04166999	
23		73738	ELBOW, EXHAUST	2	SERIAL 04167000-09999999	
24	25	35029	"O" RING, EXHAUST ELBOW TO	2		
25	10	60982	SCREW, EXHAUST ELBOW TO E	6		