



2515

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		45375A 1	TILT CYLINDER ASSEMBLY	2		
2	17	39641	ANCHOR PIN-Tilt Cylinder to Drive	1		
3	23	39639	SLEEVE-Drive Shaft Housing Anch	2		
4	23	39638	SLEEVE-Rubber-Drive Shaft Housi	2		
5	12	39637	WASHER-Drive Shaft Housing Anc	2		
6	13	37642	WAVE WASHER-Drive Shaft Hous	2		
7	24	46312	SPRING-Drive Shaft Housing Anc	2		
8	12	39782	WASHER-Rubber-Drive Shaft Hou	2		
9	12	29395	WASHER-Drive Shaft Housing Anc	2		
10	11	34932	NUT-Drive Shaft Housing Anchor F	2		
11	17	39640	ANCHOR PIN-Tilt Cylinder to Gimbe	1		
12	12	39636	WASHER-Gimbal Ring Anchor Pin	2		
13	12	36041	WASHER-Gimbal Ring Anchor Pin	2		
14	23	35278	BUSHING-Tapered-Gimbal Ring Ar	4		
15	24	46312	SPRING-Gimbal Ring Anchor Pin	2		
16	12	36042	WASHER-Gimbal Ring Anchor Pin	2		
17	11	35814	NUT-Gimbal Ring Anchor Pin	2		
18	32	38755	HYDRAULIC HOSE-Elbow to Tilt C	2		
19	23	35977	GROMMET-Hydraulic Hose	2		
20	54	22875	CLIP-Hydraulic Hose	3	(NYLON)	
20	54	28700	CLIP-Hydraulic Hose to Transom Pi	1	(Steel)	
21	10	35401	SCREW-Hydraulic Hose Clip	2	(1 IN.)	
21	10	20776	SCREW-Hydraulic Hose Clip to Tra	1	(1/2 IN.)	
21	10	57143	SCREW-Hydraulic Hose Clip	1	(3/4 IN.)	
22		22789	D-WASHER-Hydraulic Hose Clip Sc	3		
22	13	26992	LOCKWASHER-Hydraulic Hose Cli	1		
23		49200A 2	COVER ASSEMBLY-Inlet	1		
24	12	49199	WASHER-Inlet Cover	2		
25	22	38752	ELBOW-Connecting Hose to Tilt Cy	1		
26	32	57114	HYDRAULIC HOSE-Elbow to Hydr	1		