



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		56823	WIRING HARNESS, EXTERNAL	1		
2		26079	PLATE, WIRING HARNESS TO M	1		
3		56731	BRACKET MOUNTING - WIRING I	1		
4	10	46718	SCREW, WIRING HARNESS PLA	4		
5	13	26995	LOCKWASHER, WIRING HARNE	4		
6	10	58510	SCREW, MOUNTING BRACKET T	3		
7	13	46523	LOCKWASHER, MOUNTING BRA	3		
8		56620	BRACKET, MOUNTING - HARNE	1		
9	10	20055	SCREW, BRACKET TO FLYWHEE	1		
10	13	26996	LOCKWASHER, BRACKET SCRE	1		
11		39974	CLAMP, WIRING HARNESS LEA	2		
12	10	22387	SCREW, CLAMP TO MOUNTING I	2		
13	11	53153	NUT, CLAMP SCREW	2		
14	54	39788	CLIP, WIRING HARNESS	1		
15	10	25764	SCREW, WIRING HARNESS CLIP	1		
16		22789	"D" WASHER, WIRING HARNE	1		
17	11	46438	NUT, WIRING HARNESS CLIP SC	1		
18	54	46770	CLAMP, WIRING HARNESS TO V	1		
19	10	29227	SCREW, WIRING HARNESS CLAI	1		
20	11	34388	NUT, WIRING HARNESS CLAMP	1		
21	10	24231	SCREW, WIRING HARNESS LEA	1		
22	11	46438	NUT, WIRING HARNESS LEAD S	1		
23	23	32914	SLEEVE, WIRING HARNESS LEA	1		
24	54	22690	CLIP, WIRING HARNESS ATTACH	1		
25	10	25764	SCREW, WIRING HARNESS CLIP	1		
26	13	26996	LOCKWASHER, WIRING HARNE	1		
27		22789	"D" WASHER, WIRING HARNE	1		
28	11	46438	NUT, WIRING HARNESS CLIP SC	1		
29	50	58059	STARTER MOTOR ASSEMBLY (S	1		
30	10	37388	SCREW, STARTER MOTOR AND	1		
30	10	46197	SCREW, STARTER MOTOR AND	2		
31	11	34933	NUT, STARTER MOTOR AND FL	3		
32		38540	BATTERY CABLE, POSITIVE (REC	1		
33		38539	BATTERY CABLE, NEGATIVE (BL	1		
34	10	38524	SCREW, POSITIVE BATTERY CA	1		
35	13	39107	LOCKWASHER, BATTERY CABLE	1		
36	54	22627	CLAMP, BATTERY CABLE TO BO	2		
37	10	22793	SCREW, BATTERY CABLE CLAMP	2		
38		22789	"D" WASHER, BATTERY CABLE	2		
39		48952	WATER TEMPERATURE SENDEL	1		
40	13	26996	LOCKWASHER, WATER TEMPE	1		