



NOTE: FOR CONTINUITY CIRCUIT COMPONENTS, SEE THE "CONTINUITY KIT" SECTION.

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		816461A 2	GIMBAL RING ASSEMBLY	1		
2	23	99352	BEARING	1		
3	22	74036	FITTING-GREASE (1/4-28)	2		
4	19	77633	LUBRICAP	2		
5		77123	HINGE PIN	2		
6		805320A 1	SWITCH ASSEMBLY-TRIM SEND	1		
7	12	91964	WASHER	1		
8	10	37978	SCREW (#10-32 X 3/4 IN.)	4		
9	13	26996	LOCKWASHER (#10)	4		
10		57008	RETAINER	4		
11	54	12078	CLAMP	1		
12	10	28635	SCREW (1/4-20 X 5/8 IN.)	1		
13		98262A 1	LEVER ASSEMBLY-STEERING	1		
14		98230A 1	SHAFT ASSEMBLY-SWIVEL	1		
15	12	85344	WASHER (3/4 IN. I.D.)	1		
16	12	98548	WASHER (1-1/8 IN. I.D.)	1		
17	11	25599	NUT (3/4-16)	1		
18	10	807204	SCREW (7/16-20 X 2 IN.)	1		
19	11	98533	NUT (7/16-20)	1		
20		79146	RETAINER	1		
21	10	90126	SCREW (3/8-24 X 3-3/4 IN.)	2		
22	12	34931	WASHER	4		
23	11	13437 1	NUT (3/8-24)	2		
24	17	52798	PIN-CLEVIS	1	NON POWER STEERING	
25	18	46950	PIN-COTTER	1	NON POWER STEERING	
26	54	816311	STA-STRAP (8 IN.)	AR		3