



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		14336A 8	HYDRAULIC PUMP ASSEMBLY	1		
1		808728	ADAPTOR	1		
2		89493	COUPLING	1		
3		18529	PUMP (INCLUDES SCREWS)	1		
4	35	89496	FILTER	1		
5	25	89498	O-RING-MOTOR END	1		
6	25	17645	O-RING-RESERVOIR END	1		
7		41218	DIPSTICK	1		
8		18525A 1	RESERVOIR	1		
9	36	18526	CAP (WITH VENT HOLE)	1		
10	10	18527	SCREW (INCLUDES O-RING)	1		
-		17649	MOTOR	1		
11		17632	END CAP W/BEARING	1		
12	10	17626	SCREW	4		
13	25	17625	O-RING	1		
14	10	17621	SCREW	2		
15		17633	BRUSH HOLDER KIT	1		
16		17631A 1	BRUSH SET	1		
17		17623	ARMATURE	1		
18	12	17653	THRUST WASHER	2		
19		17624	FIELD AND FRAME	1		
20		17622	HOUSING W/BEARING	1		
21	10	823444	SCREW	2		
-		812498A 1	UP PRESSURE RELIEF VALVE KI	1	REPAIR KITS	
-		95353A 1	THERMAL RELIEF VALVE KIT	1	REPAIR KITS	
-		812499A 1	DOWN PRESSURE RELIEF VALV	1	REPAIR KITS	
-		18545A 1	OVERHAUL REPAIR KIT	1	REPAIR KITS	