



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		41646A 9	BELL HOUSING ASSEMBLY	1	USE WITH TRIM SENDERS	
2	12	806241	WASHER	2	USE WITH TRIM SENDERS	
3	16	59579	STUD (7/16 X 2-13/16)	6	USE WITH TRIM SENDERS	
4		41674	INSERT	1	USE WITH TRIM SENDERS	
5	25	62705	O-RING	1	USE WITH TRIM SENDERS	
7		41646A10	BELL HOUSING ASSEMBLY	1	USE WITHOUT TRIM SENDERS	
3	16	59579	STUD (7/16 X 2-13/16)	6	USE WITHOUT TRIM SENDERS	
4		41674	INSERT	1	USE WITHOUT TRIM SENDERS	
5	25	62705	O-RING	1	USE WITHOUT TRIM SENDERS	
6	23	847637	BUSHING	2	USE WITHOUT TRIM SENDERS	
7	12	35935	WASHER	6		
8	11	13439 1	NUT (7/16-20)	6		
9		86840A 3	BELLOWS ASSEMBLY-UNIVERSAL	1		
10	54	86049	CLIP-GROUNDING	1		
11	54	815504372	CLAMP	1		
12		86814	SLEEVE	1		
13		18654A 1	BELLOWS ASSEMBLY-EXHAUST	1		
13		78458A 1	TUBE-EXHAUST	1		
14	54	86049	CLIP-GROUNDING	2		
15	54	815504348	CLAMP	2		
16		815303	ADAPTOR	1		
17	32	54950 53	TUBING	1		
18	54	12994	CLIP	1		
19	54	816606	CLAMP	1		
20	22	816594A 1	FITTING ASSEMBLY	1		
21	22	56800	PLUG (1/16-27)	1		
22	22	814382	CONNECTOR	1		
23		18920A 1	VALVE ASSEMBLY	1	USE WITH OIL RESERVOIR	
24	25	48171	O-RING	2	USE WITH OIL RESERVOIR	
25	54	818557	CLAMP	2		