











Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
--		99940A 2	CONTINUITY CIRCUIT KIT	1	ALL COMPONENT PARTS ARE M	

NOTE
 All components parts of the
 Continuity Kit are not sold separately.
 Order 99940A2

COMPONENTS

Cable Assembly	Cable Assembly	Ground Plate	Hex Head Screw	Lockwasher	Self-Tapping Screw
					
					Binding Head Screw
		Ground Plate	Hex Head Screw	Lockwasher	
					Locknut
					