



14258

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		854025	BRACKET	1		
2		854026	BRACKET	1		
3	16	854027	STUD, Remote Control Cable	1		
4	11	854028	NUT, Lock	4		
5	12	854029	WASHER	3		
6		881308	CONTROL UNIT	1	(2.8L) (600 RPM)	
6		881309	CONTROL UNIT	1	(4.2L) (600 RPM)	
7		854031	SUPPORT	3		
8	11	854032	NUT, (M6)	10		
9	10	855511	SCREW, (M6 x 20)	8		
10		854034	BRACKET	1		
11		854035	TPS	1		
12		854036	LEVER, TPS	1		
13	11	854037	NUT, (M8)	1		
14		854038	SUPPORT	1	(Sterndrive)	
14		860598	SUPPORT	1	(Inboard)	
15	16	854039	STUD, TPS Lever	1		