



9847

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		22	855517 ELBOW, Transmission	2		
2			NA NOT AVAILABLE	2		
3			NA NOT AVAILABLE	2		
4	12		855516 WASHER	2		
5	22		803174 ELBOW, Transimssion Oil Cooler	2		
6	10		896332 BOLT	2		
7	54		815504272 CLAMP, Worm Gear	2		
8			NA NOT AVAILABLE	1		
9			NA NOT AVAILABLE	1		
10			NA NOT AVAILABLE	1		
11			NA NOT AVAILABLE	1		
12			865383A02 POWER STEERING ACTUATOR	1		
13	32		816172 HOSE	1		
14	54		896332085 CLAMP	2		
15	22		816339 NOZZLE	2		
16	35		860603 FILTER	1		
17	32		44348T TUBE	1		
18			865380A25 TRIM PUMP ASSEMBLY, Comple	1		
19			805013T 1 PIPE, Exhaust	1		