

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	90	860094020	OWNER'S GUIDE	1		
-	90	860074A01	SERVICE MANUAL	1		
-	90	860097040	INSTALLATION MANUAL	1		
-	37	889289	DECAL, (D4.2L 200hp)	1		
-	37	889290	DECAL, (D4.2L 230hp)	1		
-	37	889291	DECAL, (D4.2L 250hp)	1		
-	37	895430	DECAL, (D4.2L 270hp)	1		
-	37	889292	DECAL, (D4.2L 300hp)	1		
-	37	889296	DECAL, (D4.2L 320hp)	1		
-	37	895435	DECAL, (D4.2L 200hp), Logo	1		
-	37	889294	DECAL, (D4.2L 230hp), Logo	1		
-	37	895433	DECAL, (D4.2L 250hp), Logo	1		
-	37	895434	DECAL, (D4.2L 270hp), Logo	1		
-	37	895410	DECAL, (D4.2L 300hp), Logo	1		
-	37	895436	DECAL, (D4.2L 320hp), Logo	1		
-	91	889331	TOOL, Flywheel TDC Alignment Pir	1		
-		889074A 1	VALVE	1		
-		891867	LONGBLOCK, (300hp), For Electror	1		
-		898272020	LONGBLOCK, For Mechanical Eng	1		

NO IMAGE