



16980

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	854037002	NUT, (M8)	7		
2		898272007	SUPPORT, Rubber	3		
3	11	854032	NUT, (M6)	10		
4	10	854118001	SCREW	1		
5		854035	TPS	1		
6	10	896332173	SCREW	2		
7		854036	LEVER, TPS	1		
8		889891	CONTROL UNIT	1	(300hp)	
8		898248	CONTROL UNIT	1	(250hp)	
8		898249	CONTROL UNIT	1	(270hp)	
8		898250	CONTROL UNIT	1	(320hp)	
9		898140	SUPPORT, Rubber	4		
10	12	854029	WASHER	3		
11	16	854027	STUD	1		
12	11	854028	NUT, Lock	4		
13	16	854039	STUD, TPS Lever	1		
14		898272008	BRACKET	1		
15		898272009	BRACKET	1		
16	10	898272010	SCREW	2		