



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	35	882592	FILTER AND COOLER ASSEMBLY	1		
2		882688	ELEMENT AND CAP ASSEMBLY	1		
3		882687	ELEMENT-Oil Filter	1		
4	27	882689	GASKET-Center Screw	1		
5	10	882685	SCREW	1		
6		882709	COOLER ASSEMBLY-Oil	1		
7	27	882686	GASKET-Cooler to Bracket	2		
8	10	882683	SCREW-Oil Cooler	4		
9	27	882684	GASKET-Oil Filter to Cylinder Block	1		
10	32	882521	HOSE-Oil Drain	1		1
11	54	882453	CLIP-Hose, Drain	2		
12	54	882741	CLIP-Oil Pipe	1		
13	54	882742	CLIP-Oil Pipe	1		
14		882524	NIPPLE- Oil Cooler	1		
15	27	882655	GASKET-Valve, Oil Cooler	1		
16		882544	STOPPER	1		
17	10	882309	SCREW-Flange (M10 x 16)	2		
18		882415	VALVE ASSEMBLY-Relief	1		
19		882436	VALVE ASSEMBLY-Relief	1		
20	27	882383	GASKET-Relief Valve	1		
21		882397	PIPE-Oil Return	1		
22	32	882587	HOSE-Thermo Valve to Oil Cooler	1		
23	54	882453	CLAMP-Hose	2		
24	32	882576	HOSE-Oil Cooler to Water Pipe	1		