



NSS = Not Sold Separately

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
		882481	STARTER ASSEMBLY-Complete	1		
1		882448	BRACKET-Center	1		
2		882446	HOLDER-Brush	1		
3	10	882389	SCREW	2		
4	87	889903	SOLENOID ASSEMBLY	1		1
5		882522	GEAR- Starter Pinion	1		
6	12	882605	WASHER KIT- Starter	1		
7		882606	METAL KIT- Starter	1		
8	11	889904	NUT	3		1