



TURBOCHARGER SYSTEM

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		882562	TURBOCHARGER ASSEMBLY	1	
2	27	882564	GASKET-Turbocharger to Exhaust	1	2,3
3		882563	PIPE-Exhaust,Turbocharger	1	
4	11	882341	NUT (M10)	6	
5	16	882336	STUD	3	
6	16	882432	STUD	4	
7	13	882346	LOCKWASHER	4	
8	32	882337	HOSE	1	
9	54	882357	CLIP	2	
10		882559	BRACKET-Intake Pipe	1	
11	32	882578	HOSE-Intake	1	
12	10	882674	SCREW (M8 x 75)	2	
13	10	882325	SCREW w/Lockwasher (M8 x 25)	2	
14	27	882514	GASKET-Inlet Pipe	1	
15	10	882299	SCREW-Flange (M8 x 16)	2	
16	27	882653	GASKET-Water Pipe	2	2
17	22	882731	ADAPTOR-Water	1	
18	10	882349	SCREW (M12 x 24)	1	
19	54	882357	CLIP-Inlet Hose	2	
20	27	882565	GASKET-Turbocharger to Adaptor	1	
21	12	882343	WASHER	4	
22		882586	DUCT-Air, Turbocharger	1	
23	22	882647	PLUG-Taper	1	
24	11	882338	NUT-Flange	4	
25	10	882320	SCREW w/Lockwasher (M8 x 18)	8	
26	10	882732	SCREW w/Lockwasher (M8 x 22)	2	
27		882377	SILENCER ASSEMBLY-Turbochar	1	
28		882558	DUCT-Intake, Turbo	1	
29	32	882574	HOSE	1	
30	32	882575	HOSE	1	
31	54	882425	CLIP-PVC	2	
32	54	882453	CLIP-PVC	2	
33		882545	SEPERATOR-Oil	1	
34	10	882320	SCREW w/ Washer (M8 x 18)	2	
35		889340	SHIELD-Heat (Turbo)	1	1
36	32	882550	PIPE-Water Drain	1	
37	32	863239	HOSE-To Transom	1	