



14196

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		814874	SEAWATER PUMP ASSEMBLY	1		
2	10	801332604	SCREW	1		
3	17	801332620	PIN	1		
4	30	801330116	BEARING	2		
5		801332599	SPREADER	1		
6	53	801332595	RING, Retaining	1		
7	45	801332593	SHAFT	1		
8	12	801332601	WEAR PLATE	1		
9	26	801332600	SEAL	2		
10		801332599	SPREADER	1		
11	25	801332598	O-RING	1		
12		814873	CAM	1		
13	47	801332602	IMPELLER	1		
14	27	801332606	GASKET	1		
15		801332607	COVER	1		
16	10	801332608	SCREW	6		
17	25	801333850	O-RING	1		
18	11	40021 2	NUT, (M6)	4		
19	32	805375	HOSE	1		
20	54	815504228	CLAMP, Worm Gear	1		
21	54	815504232	CLAMP, Worm Gear	1		
22	32	806441	HOSE	1		
23	54	815504220	CLAMP, Worm Gear	2		
24	32	816173	FITTING	1		