



A = FRONT COVER

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805884T	ALTERNATOR	1		
2	12	96457	WASHER-PHENOLIC	1		
3	13	26992	LOCKWASHER (1/4 IN.)	1		
4	11	94330	NUT (1/4-20)	1		
5	13	26996	LOCKWASHER (#10)	2		
6	11	79989	NUT (#10-24)	2		
7		879716	BRACKET-ALTERNATOR	1		
8	10	854181	SCREW (M8)	1		
9	13	811460	LOCKWASHER	1		
10	11	854184	NUT (M8)	1		
11	10	855508	SCREW (M14 X 25)	2		
12		806980T	BRACE	1		
13	10	35386	SCREW (5/16-18 X 1 IN.)	1		
14	13	53166	LOCKWASHER (5/16)	1		
15	12	814806	WASHER	1		
16	10	40003 82	SCREW (M10 X 50)	1		
17	23	807030	SPACER	1		
18	12	811479	WASHER	1		
19	11	40136 10	NUT (M10)	1		
20	57	64032A 1	V BELT	1		